

ADIABATIC COOLING SOLUTION

# 2HP

OUTDOOR REFRIGERATION UNIT



INSTALLATION MANUAL

OCU-CR200VF5 / OCU-CR200VF5SL

# CONTENTS

## 01 GENERAL INFORMATION

1.1	Symbols	3
1.2	Stop Think Act	5
1.3	Staff Training	5
1.4	Electrical Connections	5
1.5	Refrigerants	6
1.6	Rated Specification	6

## 02 PRE-INSTALLATION

2.1	Name of Each part	7
2.2	Operating Environment	8
2.3	Handling and Transporting Cases	8
2.4	Shipping Damages and Shortages	8
2.5	Rating Plates	9

## 03 INSTALLATION

3.1-3.22	Frame Assembly	10-18
----------	----------------	-------

## WIRING AND CIRCUIT DIAGRAM

3.23	Connect solenoid valve to the unit controller	19-23
3.24	Wiring Diagram	24

## 04 MAINTENANCE AND INSPECTION

4.1	Commissioning	25
4.2	Care	25
4.3	Daily Checks	25
4.4	Six Monthly Maintenance	26
4.5	Evaporating cooling pad replacement	27-28

## 05 SPRINKLING CONTROL AND TEMPERATURE SETTINGS

5.1	Controller Settings	29
-----	---------------------	----

## 06 DECOMMISSIONING & DISPOSAL

6.1	Decommissioning	30
6.2	Disposal	30

## 07 TROUBLESHOOTING

7.1	Troubleshooting	31
7.2	Action at the time of failure	31

## 08 APPENDIX

8.1	Appendix 1 - Risk analysis	32
8.2	Appendix 2 - Warranty	33
8.3	Appendix 3- Disclaimer	33
8.4	Appendix 4 - Liability	33

# GENERAL INFORMATION

## 1.1 SYMBOLS:



**NOTE:** Not related to personal injury – Indicate[s] situations, which if not avoided, could result in damage to equipment



**CAUTION:** Indicate(s) hazardous situation which, if not avoided, will result in moderate injury.



**CAUTION:** Indicate(s) hazardous situation which, if not avoided, will result in moderate or serious injury.



**CAUTION:** Indicate(s) hazardous situation which, if not avoided, will result in serious injury or death.



**USE MANUAL:** Be sure to follow the instruction thoroughly whilst doing the installation. If not performed correctly, leakage, electric shock or fire may occur. Always keep manual in safe place.



**NO WALK:** Do not walk on top or on any parts of the unit. Unit damages or personal injuries may occur.



**NO SIT:** Do not sit on top or on any parts of the unit. Unit damages or personal injuries may occur.



**NO CLIMB:** Do not climb on top or on any parts of the unit. This may cause damage to the unit or personal injury.



**NO CHEMICALS:** Do not use chemical substances to clean the unit. This may cause discoloration or could damage the unit.



**NO WET AREA:** Do not install unit in a wet place or near water. Risk of Electricity leakage or electrical shock may occur.



**NO DIRECT WATER:** Do not pour excessive water onto the unit. DO NOT use pressurised hose, eg fire hose. This can result in electric shock.



**PPE GEAR :** Remember to wear Personal Protective Equipment whilst installing the case.

# GENERAL INFORMATION


## 1.1 SYMBOLS:



**TURN OFF:** Ensure that power source is disconnected when conducting any servicing or inspection. Injuries such as electric shock or burns could occur.



**NO FLAMMABLE:** Do not expose the case to any flammable objects. This may cause ignition and explosion due to spark.



**PRESSURE & VACCUUM TEST :** Ensure a pressure and Vacuum test is conducted. The leakage of refrigerant may result in poor performance or malfunction of the unit.




**NO GAS:** Do not install the unit where flammable gas could be released. If gas leaks out and flows around the unit there can be risk for fire.



**EARTHING :** Ensure unit earthed when proceeding with electrical components. Electric shock or fire may occur if not correctly processed.



**TECHNICIANS ONLY:** Installation should only be performed by qualified technicians.




**NO OBJECTS ON UNIT:** Do not place objects, stack or use the top of the unit as storage. Object may fall and cause injury to personnel and /or damage to the unit.



**NO A/C:** Do not install case where air blows directly at the unit. This will disrupt the unit airflow and affect performance.



**NO WET HANDS:** Ensure not to touch switches or any component with wet hands. This may cause electrical shock.



**NO FLAMMABLE :** Do not keep any volatile or flammable materials inside the unit. It may risk explosion or fire.



**NO CONNECTING SOCKETS:** Do not use any connecting socket or extension cords. Be sure to use private line or socket as the main power source. Failure to do so could result in electric shock or fire.

# GENERAL INFORMATION


## 1.2 STOP THINK ACT



**STOP:** Take the time to think about the installation process. Consider the outcomes of the actions needed to be taken, worst thing that could happen?



**THINK:** How are you going to do it, is it the safest way? if not, how can you do it better? Do I have the right PPE, tools and equipment.



**ACT:** Go about it in the safest way possible. Follow this installation manual here and don't rush. STOP if it can't be done safely.



**NOTE:** These refrigeration units are heavy, use appropriate PPE and tools and manpower levels.

## 1.3 STAFF TRAINING

This manual is to be used to understand and safely execute the installation & maintenance of the appliance. It is the installer & user's responsibility to carry out the instructions illustrated within the manual correctly. The installer & user is responsible for setting out the training and requirements needed for their maintenance technician staff to be educated to use the unit correctly. The unit should always be kept in good working order to ensure installer and user safety.

Injury to personnel and damage to the unit and its components may occur if instructions in the manual are not correctly followed. If information would like to be added to this manual, or if suggestions would like to be made, contact Hussmann directly at any time.

## 1.4 ELECTRICAL CONNECTION

Check that the power supply voltage matches that displayed on the rating plate of the refrigeration unit, and that the power is adequate. Voltage provided should be  $\pm 10\%$  of rating plate. Electrical should be hard wired by an authorised electrician to comply with all local electrical regulations. Failure to do so could result in electric shock or fire.

### **Always use a dedicated circuit and install a ground fault protector.**

Incorrect electrical work may lead to current leak and fire or electrical shock.

- Wiring work should conform to the installation instructions.

### **Electrical wiring should use the specified cable and to be properly secured.**

When the specified cable is not used, or connection or securing is incomplete, electrical resistance becomes larger and may cause abnormal heating or fire.

- Use the specified cable and properly secure it on an appropriate location.

### **Grounding Work**

Lack of grounding work may lead to electrical shock caused by current leak.

- Securely carry out grounding work by qualified technicians.

### **Securely place the cover on the solenoid valve.**

Incomplete attachment may lead to penetration of water, thereby causing current leak and fire/electrical shock.

- Confirm that solenoid valve cover is securely installed



# GENERAL INFORMATION

## 1.5 REFRIGERANTS



Installation & Maintenance must be performed by qualified technical personnel with appropriate training and authorisation to work with flammable refrigerants.

### CO<sub>2</sub>:

The refrigerant CO<sub>2</sub> is a high pressure gas that is compatible with the environment, but is not flammable. Pay close attention during transport, installation and dismantling not to damage the refrigerant pipelines.



**CAUTION:** Gas is under high pressure.

### EVENT OF DAMAGE:



Keep surrounding flames or sources of ignition away from the appliance. Properly ventilate the premises and use a breathing apparatus. Turn the unit off and notify the customer service department. Fire and heat may cause gas receptacles to rupture. Use water spray/ not jet or fog to extinguish.

## 1.6 RATED SPECIFICATION

Item	Rating	Unit
Power Source	~50 Hz	V
Current	4.6 A	A
Phase	Single Phase	-
Operation Intake Air Temp	On=32° C, OFF=28° C	Degree Celcius
Water Consumption	3L / Min	L/Min
Protection class	IP65 with connector	

# PRE INSTALLATION

## 2.1 Name of Each Part



# PRE INSTALLATION

## 2.2 OPERATING ENVIRONMENT

To avoid condensation build-up, unit should be positioned to allow air to freely circulate around the underside and rear of the unit (refer page 7). 2HP Refrigeration unit must be level.

Place the refrigeration unit on a firm foundation to avoid an increase of noise and vibration case.

## 2.3 HANDLING AND TRANSPORTING CASES

2HP Refrigeration unit dimensions and weight can be found on the rating plate.

Always ensure that the moving device is of a suitable type, and has sufficient lifting capacity for the case weight and dimension. Always lift unit from the underside.




**NOTE:** These units are heavy, use appropriate PPE and tools and manpower levels.

It is the responsibility of the transport company to insure adequate loading strategies are implemented to insure the safe transportation of the unit. The 2HP refrigeration unit need to be secured correctly during road transport to insure damage free delivery.

Disregarding the necessary implementation of correct protection Warehouse Managers may refuse loading. Transportation requirements are to ensure unit integrity and prevent unnecessary damage and avoid delays in the unit installation schedule.

Before storing the unit, ensure packaging is unbroken and does not display defect that may compromise preservation of the unit.



### Avoid UV rays:

Permanent deformation of plastic materials or damage of unit parts. **DO NOT** store the unit in uncovered areas exposed to atmospheric agents and to direct sunlight.

## 2.4 SHIPPING DAMAGES AND SHORTAGES

Packaging needs to be disposed of responsibly (refer to page 32). by the installer and/or user.



**Where possible please recycle as many items as possible.**

After removing packaging, inspect the unit for any shipping damage. Immediately report any shipping damage to the carrier and inform Hussmann Customer Service of any short supplies.

Where possible all packaging and shipping braces should be removed before unit are put into there approx final position.

- Apparent loss or damage. If there is an obvious loss or damage it must be noted on the freight documentation receipt supplied by the Transport Company and notification to Hussmann or representative within seven (7) days of delivery.
- Concealed loss or damage after removing all packing etc confirm with the parts list, attached to the unit for any short supplied and or damaged parts etc. If required notify Hussmann or representative within seven (7) days of delivery.



# PRE INSTALLATION

## 2.4 SHIPPING DAMAGES AND SHORTAGES



**NOTE:** Refer to product MSDS for all hazardous substances used during installation in relation to their application, PPE, first aid, disposal and emergency management. Refer page 29 (Risk Analysis) For MSDS sheet contact your Hussmann



**CAUTION:** Care must be taken to avoid damage to solenoid valve box and electrical cable mounted under or at the left hand side of the unit

**INSPECT UNDERSIDE BEFORE LIFTING WITH FORKLIFT.**



**CAUTION:** When moving the unit confirm that the equipment used is approved for such works.



Refer to your companies' safe working procedure (SWP) when handling unit such as forklifts etc.

## 2.5 RATING PLATE:


**Each unit has a unique rating plate which include the model number.**

The rating plate for the 10HP Refrigeration unit is located at the bottom right hand corner.




**NOTE:** Refer to rating plate to identify the exact model, Serial number, weight, Refrigerant, Voltage and Amperage etc.

## RATING PLATE:



## LOCATIONS:




Rating Plate


# INSTALLATION

## 3.1 FRAME ASSEMBLY

Remove four existing screws from the top and right panels of the unit. Keep the screws for the step 14.




**3.2** Mount the left side panel. Use the existing holes and screws on the unit to fix the panel and avoid drilling.




**NOTE:** Information in this manual is to be followed in conjunction with specifications, work practices and regulations of the customer, installing company and relevant industry.

**3.3** Next, assemble the structure of adiabatic cooling solution using screws to fix the inner corner bracket to the bottom panel.




**3.4** Next, assemble the structure of adiabatic cooling solution using screws to fix the inner corner bracket to the bottom panel.




# INSTALLATION


- 3.5A** Fix the drain brackets using the PVC valve socket, faucet socket and rubber seal. Ensure that the two holes are aligned, the drain bracket corners are sealed and the PVC socket is tightened to avoid leakage. Use thread seal tape where necessary.




## 3.5B




## 3.5C




- 3.6** Place the joint drain brackets on to the bottom panel.



- 3.7** Insert the cooling pad holder bracket into the drain bracket




- 3.8** Insert the cooling pads onto the drain. Noted that as you insert the cooling pads, they will be sitting on top of the PVC sitting which prevents them from touching the drain bottom.




# INSTALLATION

- 3.9** Connect the pipes to one another using an elbow and ensure that pipe holes are facing downwards. The insert the PVC end cap.


**WARNING:** Before Gluing the pipes ensure that pipe holes are facing downwards, and it is tightened to avoid leakage.




- 3.10** Place the connected pipes on the right-side panel and inner corner bracket flange as show.



- 3.11** Fix the top panel to the inner corner bracket and the right-side panel using screws




- 3.12** Fix the corner bracket and screw it from the top. The corner bracket bottom flange should hold the bottom panel.



# INSTALLATION

- 3.13** Hold the assembled unit from the top and bottom and slide into the left side panel attached onto the unit. Ensure that the bottom bracket sits on the left side panel flange as shown below.

**WARNING:** This step may require help to be completed.




**FIG. A**




**FIG. B**

- 3.14** Fix the assembly onto the unit using the right-side panel by using the existing screws and holes on the 2HP unit.




- 3.15** Screw the top panel to the left side panel




# INSTALLATION

- 3.16** Connect the pipe to the water pipe using a 90° 20mm elbow.  
**WARNING:** Do not glue the elbow at this step until the valve box is installed.



- 3.17** Place the joined water pipes on the installed brackets slot from the top.






# INSTALLATION


## 3.18A Reducer assembly with Flow control disc and rubber gasket

Insert the flow control disc and the rubber gasket into the Female-Female reducer and then connect the Female-Male reducer as shown in Fig. 3.17A below.




**Fig. 3.17A Flow Control Disc installation**

## 3.18B. The reducer assembly should look as shown in Fig. 3.17B and Fig 3.17C below after inserting the disc and gasket.



**Fig. 3.17B. Left Side view of inserted flow control disc and**




**Fig. 3.17C. Reducer Assembly with Flow control Disc and Rubber Gasket**

## 3.19. Steps for installing pressure reducing valve and solenoid valve to PVC water pipes


- Step 1: Connect the sprinkler adapter to ball valve.
- Step 2: Connect the ball valve to a male pipe nipple threaded 3/4"
- Step 3: Connect the male pipe nipple threaded 3/4" to the solenoid valve
- Step 4: Connect the solenoid valve to a second male pipe nipple threaded 3/4" .
- Step 5: Connect second male pipe nipple threaded 3/4" to the pressure reducing valve.
- Step 6: Connect the pressure reducing valve to a third male pipe nipple threaded 3/4".
- Step 7: Connect the third male pipe nipple threaded 3/4" to the pre assembled reducers from Fig. 3.17A.
- Step 8: Connect pre assemble Female-Female Reducer to your Grey PVC socket. Make sure the Flow control disc and rubber gaskets are fitted tightly and at correct location. Refer Fig 3.18A. for correct installation.

# INSTALLATION



**Fig. 3.19A Sequential installation of parts**

**NOTE:** Use seal tape on all joints and ensure that the sockets are tightened to avoid leakage.  
**NOTE:** Ensure the Solenoid Valve and Pressure Reducing Valve flow direction is as marked below.




**Fig. 3.19B Final setup of valves**






# INSTALLATION


- 3.20** Assemble the setup shown in fig 18A and then assemble the grey PVC socket to PVC pipes using the elbow as shown below.




- 3.21** Insert the universal bush into the valve box bracket and fix the to the valve assembly and fittings to the valve bracket using cable ties. Ensure that the elbow angle is appropriate and use PVC glue to fix the piping as marked.



- 3.21A** Connect the pressure gauge provided with kit to the pressure reducing valve as shown in figure below and have the water pipe/hose connected to water inlet as marked below.



- 3.21B** Connect the water pipe / hose into the water inlet as marked



# INSTALLATION

## 3.22 Test run for leakage testing and adjusting the water pressure

**WARNING:** Perform a test run to ensure that the joints are sealed and there is no leakage.  
In case of leakage tighten the valve fittings and use silicon to reseal the drain brackets.

To test run:

- Ensure water source is connected to the water inlet and tighten.
- Set the solenoid valve state to "Open" manually by placing a magnet on top.

**NOTE: The solenoid valve is normally closed. Opening it manually will allow the water to flow**

- Open the manual ball valve completely
- Tune the pressure reducing valve to 0.6 bar with the help of pressure gauge connected.
- Monitor the water flow to be sufficient across the cooling pads and ensure that there is no leakage from the pipe fittings and the drain.

**WARNING:** During this test, if the water flow is high or low than it is needed, use the pressure reducing valve to control the water flow and set it for required pressure.


- After checking for leakage and the optimal water flow. Close the ball valve. Remove the magnet and put back the solenoid valve.

- Remove the pressure gauge from the pressure reducing valve and put back the green seal as shown below.

Seal



- After fitting back the seal completely open the ball valve and take out the handle from the ball valve as shown below.



Manual valve handle removed



## WATERFLOW

**NOTE:** Ensure that the waterflow on site supply must maintain a consistent flow.


If water flow is not consistent, a dynamic valve is recommended to be installed.




# WIRING AND CIRCUIT DIAGRAM

Electrical work must be carried out by a certified electrician according to the local requirements, regulations and laws.


## 3.23 POWER AND SOLENOID VALVE CONNECTION WIRING DIAGRAM




**STEP A.** Power connection to the unit. Feed a single phase 10A power plug cable to the unit through the lower right hand side access panel and attached with a cable gland.



**STEP B.** Remove the front panel to gain access to the electrical controller.



**STEP C.** With the unit open. Feed this cable up through the wire access holes as indicated.




**WARNING:-** To avoid serious injury from electrical shock, always disconnect the electrical power at the main when replacing or fitting any electrical component.



# WIRING AND CIRCUIT DIAGRAM


**STEP D.** Connect the power cable to the terminal strip label POWER SOURCE.




**3.22** Connect 240V solenoid valve to the unit controller.

**WARNING:- To avoid serious injury from electrical shock, always disconnect the electrical power at the main when replacing or fitting any electrical component.**


**STEP A.** Connect a new 3 x 0.75mm<sup>2</sup> shielded cable for 240V solenoid valve. Connect the active brown wire to the terminal block (L). Connect the neutral blue wire to the terminal block (10). Connect the Green/yellow earth wire to the Earth screw.



**STEP B.** Connect a second neutral wire to terminal block 9 and terminal block (N)




**STEP C.** Crimp and use a fork connector to attached the second neutral wire and power cable neutral wire together to terminal block (N). Crimp and use a fork connector to attached the solenoid active wire and power cable active wire together to terminal block (L).




# WIRING AND CIRCUIT DIAGRAM

**STEP D.** Feed the 3 core solenoid valve shielded cable through the rectangular wiring access hole and run the cable out through the bottom front lower panel wiring access hole.



Rectangular Wiring Access Area



Wiring Access Lower Panel Hole


**STEP E.** Attached a cable gland to the unit and place the 3 core cable into a conduit. Run the cable/conduit out of the unit and towards the solenoid valve as pictured.



Run Cable/ Conduit toward the solenoid valve

Attached a cable gland

**STEP F.** Feed the cable/conduit through the universal bush as pictured.



Universal Bush



Feed cable/conduit through the Universal Bush

**STEP G.** Loosen the top nut and remove the coil from the solenoid valve.



Unscrew nut

**STEP H.** Unscrew the housing cover and unscrew the side cap.



Unscrew housing cover




Unscrew side cap




# WIRING AND CIRCUIT DIAGRAM


**STEP i.** Once the side cap has been remove. Take out the washer and seal.




**STEP J.** Insert 3 core shielded cable through the side cap, washer, seal and coil housing.



**STEP K.** Connect the 3 core shielded cable to active brown wire (label 1)  
Connect the neutral blue wire to (label 2)  
Connect the earth wire Green/yellow wire to (label Earth).




**STEP L.** Screw back the housing cover and tighten the side cap.



**STEP M.** Insert the coil back to the solenoid valve and tighten the nut.



**STEP N.** Mount the valve box onto the valve box bracket and use screws to fix it.



# WIRING AND CIRCUIT DIAGRAM

**STEP O.** Attached the cable clip to the conduit and screw onto the front panel.



Attached cable clip



**Note:-** Rechecking electrical termination for tightness. During wiring the solenoid valve. It is a requirement to check the electrical connection for tightness and re-tension where needed prior to powering up the equipment.



## Cautions for Electrical Wiring Work


Electrical Shock and Fire Prevention

- (1) Apply grounding wiring.
- (2) The circuit must not be shared with other circuits. (The wire should not be shared with other equipment)
- (3) Electric wire should not touch high temperature components (compressor, gas cooler, discharge piping, etc.) and any metal edge.



# WIRING AND CIRCUIT DIAGRAM

## 3.24. Adiabatic cooling solution with solenoid valve wiring diagram.





# MAINTENANCE AND INSPECTION

## 4.1 COMMISSIONING

### START UP & CHECKS

- Check supply power is ready and correct voltage. (by Licensed Person)
- Confirm correct operation of RCD (if fitted) (by Licensed Person)
- Ensure that the solenoid valve is installed the right way up (refer to 3.22 section)
- Check that all pvc pipe are installed correctly



**NOTE:** Verify all electrical termination during commissioning. It is a requirement to check all electrical connections for tightness, where appropriate all electrical connections must be re-tensioned prior to powering up the cabinet.

### TURN POWER ON

- Check that all pvc pipe are not leaking
- Check if the evaporative cooling pads are fitted and secure in place.
- Check that the water hose to the solenoid valve is not leaking.
- After start-up, check that the 2HP refrigeration unit is running correctly.

## 4.2 CARE AND CLEANING

Long life and satisfactory performance of any equipment is dependent upon the care it receives. To ensure long life, proper sanitation and minimum maintenance costs, this unit should be well ventilated and all debris removed.

## 4.3 DAILY CHECKS

- Check for any water leakage from pvc pipe
- Check for any water leakage connection from water hose to solenoid valve
- Check evaporative cooling pads are secure in place.
- Visually check the 2HP refrigeration unit for any damage and take appropriate remedial action (Call a licence technician or call Hussmann)



**CAUTION:** If any damaged electrical components are identified during inspection isolate case power and contact service contractor.

### CLEANING

A thorough cleaning and service of the 2HP refrigeration unit should be carried out by qualified refrigeration and electrical engineers on a six monthly basis. Please contact Hussmann Pty Ltd or your service provider.

### DO NOT USE:

- DO NOT use abrasive, solvent, ammonia or oil-based cleaners.
- When flushing the waste drain, do not use high pressure water hoses and be careful not to introduce water faster than the waste outlet/drain can drain it.
- DO NOT use steam cleaning equipment.
- DO NOT use excessive force.
- DO NOT use high pressure cleaning equipment. This may cause injury to the installer or user and may damage unit.



# CLEANING & MAINTENANCE

## 4.4 SIX MONTHLY MAINTENANCE

A thorough cleaning and maintenance check should be carried out on a six monthly basis by qualified and approved refrigeration and electrical engineers. The following procedures should be undertaken as a minimum.



**CAUTION:** If any damaged electrical components are identified during inspection isolate case power and contact service contractor.

Validate all electrical termination has been tightened once more.

Check all electrical connections for tightness and re-tensioned where needed prior to powering up the 2HP unit.

1. Isolate power.
2. Remove the evaporative cooling pads and clean the drain extrusions and drain outlets accordingly.
3. Ensure the drain is free flowing. Refrain from adding excessive water that will not be able to be drained as rapidly as poured.
4. Inspect the evaporative cooling pads for sign of worn, deteriorating or tear. If required ideally replace them (See evaporative cooling pad replacement section 4.5).
5. Visual check solenoid valve for wear and tear or broken. If broken (Call a licence electrician to replaced soleniod valve)
6. Ensure all cable connections, including screw terminals, earth leads and straps, are secure.
7. Ensure that the correct fuse rating and type is fitted for all circuits.
8. Ensure that there are no refrigerant leaks.
9. Check that all case panels, pvc pipe and extrusions are secure and undamaged.
10. Check for rust or paint damage.
11. Safely switch power to the unit back on.

### With case power turned on:

12. Check that solenoid valve and controls are working correctly.

12. Check for any water leakage from pvc pipe
13. Check for any water leakage connection from water hose to solenoid valve
14. Check evaporative cooling pads are secure in place.
15. Allow the unit to attain correct working condition.




**NOTE:** The structural components of adiabatic cooling solution do not last permanently but include those wearing out in a certain period of time.

**OPTIONAL:** To prolong the evaporative cooling pad lifespan, it is recommended to install pre-filter on the air-inlet side. This is to avoid dust clogging in the pads.


# MAINTENANCE AND INSPECTION

## EVAPORATIVE COOLING PAD REPLACEMENT


- 4.5** Unscrew the removable corner bracket from the top.




- 4.52** Remove the top bracket.



- 4.51** Unscrew and top panel from both sides of the adiabatic cooling solution.




- 4.53** Remove the old evaporative cooling pads




# MAINTENANCE AND INSPECTION

## EVAPORATIVE COOLING PAD REPLACEMENT


**4.54** Place the new evaporative cooling pads.




**4.55** Install back the top panel.



**4.56** Screw back the top panel to the side panels.



**4.57** Place and screw back the removable corner ratchet.



# SPRINKLING CONTROL & TEMPERATURE SETTINGS

## 5.1 CONTROLLER SETTINGS

### Setting method of sprinkling control for 2HP CO2 condensing unit

Target model: OCU-CR200VF5  
OCU-CR200VF5A

#### To activate Adiabatic solution

1. Turn ON No.8 of 8P DIP switch (SW13).
2. Set the rotary switch (SW11) to "ALM HISTORY"
3. Operate the ▲/▼ switch and change the setting to ON.
4. Set the rotary switch back to "OPERATION".
5. Turn OFF No.8 of 8P DIP switch (SW13).

#### Set Adiabatic ON/OFF ambient temperature.

1. Turn ON No. 5 of 8P DIP switch (SW13).
2. Set the rotary switch (SW11) to "ON"
3. Operate the ▲/▼ switch and change the setting. Adiabatic ON temperature (20°C~ 40°C) Set to 32
4. Operate the ▲/▼ switch and change the setting. Set the Adiabatic OFF temperature by difference from ON value (1°C~ 20°C). Set to 4
5. Set the rotary switch back to "OPERATION"
6. Turn OFF No.5 of 8P DIP switch (SW13).

# DECOMMISSIONING & DISPOSAL

## 6.1 DECOMMISSIONING

Plan and risk assess the decommissioning process to include the following:

- Disconnect all services. Disconnection is to be undertaken by qualified persons only.
- Removal of the refrigeration unit is to be in the reverse order of installation listed previously.
- Dismantle the refrigeration unit in accordance with the local laws on waste disposal and in respect of the environment in which we live.



## 6.2 DISPOSAL

The refrigeration unit must be disposed of in accordance with local authority guidelines.

**75%** of the materials in this refrigeration unit are able to be recycled; the materials in this case are as follows;

- **Sheet Metal** and other various metals.
- **Copper / Aluminum**
- **Cardboard**
- **PVC**

Remaining by commercial waste management



# TROUBLESHOOTING

## 7.1 TROUBLESHOOT TABLE

ISSUE	POSSIBLE REASON	REMEDIAL ACTION
<b>Solenoid Valve</b>	Water flow is not initiated while temperature reaching to its limit.	Check Solenoid valve. Check its settings, power and lose connection.
<b>Low water pressure</b>	This can be due to the position of the manual valve.	Ensure that the manual ball valve is at its open position and then check if the water piping is clogged. It may also be due to low water supply pressure or pipe clogged which may require cleaning or pipe replacement.
<b>Water leakage</b>	PVC pipe broken or not seal correctly. Drain bracket broken or not seal correctly.	Check pipe fittings and ensure that they are fasten tightly and used plumbing seal taped. If there is any leakage from the drain brackets check the water sealant hasn't degraded. If leakage still present resealing of the drain brackets using silicon may be required.
<b>Drain extrusions blocked</b>	Drain brackets might be clogged with dirt.	Remove the evaporative cooling pads and clean the drain extrusions and drain outlets accordingly.
<b>Evaporative cooling pad</b>	Worn pad and sign of Deteriorating	Inspect the evaporative cooling pads and if required ideally replace them within 1-2 years to avoid clogs of dirt

## 7.2 ACTION AT THE TIME OF FAILURE

When the adiabatic cooling solution fails to operate, close the water supply manual ball valve to avoid over flow. To avoid failure recurrence, use caution for the following.

- (1) To avoid recurrence of the same failure, execute reliable failure diagnosis and identify the true cause before starting a repair.
- (2) When the piping is to be corrected, be sure to close the water supply and disconnect the solenoid valve from the power supply. Disconnect is to be undertaken by qualified persons only.
- (3) Always check and if necessary, shut down power and restart the unit.



**CAUTION:** If any damaged electrical components are identified during inspection isolate case power and contact service contractor.



# APPENDIX

## 8.1 APPENDIX 1 - Risk Analysis

HAZARD	CONTROL MEASURES
<b>Electrical</b> - Replacement of solenoid valve	Request a service call. Electrically isolate unit before works
<b>Ergonomic</b> - Moving/ positioning/ adjusting unit	Staff must be trained in the correct procedures for setting up unit and ergonomic practices. PPE must be worn
<b>Falling</b> -Connecting wiring during installation	Use of barriers & fall arrest systems as appropriate & in accordance with State & Territory Legislation. Safe working at heights
<b>Falling</b> - Climbing on 2HP refrigeration unit	Staff must be trained in OH&S procedures. MUST not climb on unit.
<b>Slipping</b> - Drain may leak or become blocked causing water spillage	Visual Inspection and regular maintenance. Request service call when necessary.
<b>Cuts and stabbing</b> - Potential for cuts caused by damaged or missing parts	Visual Inspection and regular maintenance. Request service call when necessary. PPE must be worn when handling broken or damaged parts.



# APPENDIX

## 8.2 APPENDIX 2 - WARRANTY

The information in this manual is for **“Qualified Persons Only”**. It is **NOT** an Installation Guide for **“NON Qualified Persons”**.

To obtain additional warranty information or other support, contact your nearest Hussmann representative.

**Please include the following:**

Customer site location.  
Model number of product.  
Reason for warranty.



**NOTE:** Failure to comply with the instructions in this manual shall void the warranty.

## 8.3 APPENDIX 3 - DISCLAIMER

Hussmann reserves the right to modify the components within the case, as well as alter the descriptions and instructions provided in the manual.

In order to obtain the latest manual, please contact your nearest Hussmann representative.

## 8.4 APPENDIX 4 - LIABILITIES

The manufacturer is not liable for:

- Defects in the electrical power supply
- Failure to comply with instructions
- Interventions carried out by unqualified/untrained personnel
- Improper, incorrect and unreasonable use of the unit
- Non-compliance of maintenance and cleaning schedules as recommended by Hussmann.
- Use of accessories that are not provided nor authorized by Hussmann.
- Unauthorized modifications and interventions
- Incorrect installation not performed in accordance with the norms indicated
- Use of non-original spare parts

**HUSSmann®**